



LOGIN		<b>1 2 3</b>	 5' inactivity = Automatic LOGOUT 5' inattività = Automatico LOGOUT	 = OK
DMX MODE	DMX MODE SETTING		Enter the corresponding "IR" value ( see DMX chart Mode Column) to select the desired DMX Mode (e.g.: for IR=4press button 4). Immettere il valore "IR" corrispondente (vedi colonna DMX chart Mode) per selezionare la modalità DMX desiderata (es.: per IR=4 premere il pulsante 4).	 = OK
	DMX ADDRESS SETTING		001~512	 = OK
MASTER/SLAVE AUTOMATIC MODE TO BE USED ONLY WITH DMX MODE #1	AUTOMATIC/MASTER	 Green-Cyan-Blue-Magenta-Red-Yellow-White.	 	 5"→10"→20"→ 40"  40"→ 20"→ 10"→ 5" 
	SLAVE FIXTURE SETTING		001	 = OK
FIXED COLOR MODE (RGB-RGBW-DW) TO BE USED ONLY WITH DMX MODE #1			<b>RGB</b> 1 = RED 2= GREEN 3 = BLUE <b>DW</b> 5 = WARM WHITE 6 = COLD WHITE	 0%→100% 
DIMMER MODE (Monochromatic) TO BE USED ONLY WITH DMX MODE #1				100%→0% 
LOGOUT			<b>1</b>	
RESET			<b>7 8 9</b>	Reset to default settings
WIRELESS			1 = Unlink 2= wireless LED status ON 3= wireless LED status OFF	

\* WARNING ! in this mode, no other DMX control device must be present along the line.

ATTENZIONE ! in questa modalità non devono essere presenti altri controller DMX sulla linea.

Si raccomanda di usare batterie NUOVE AAA/R03/UM-4 alcaline e di sostituirlle una volta all'anno.  
Come controllare la carica delle batterie:  
Il lampeggio del LED rosso non è indice di funzionamento, ma di BATTERIA SCARICA!  
Per controllare lo stato delle batterie procedere così:  
1. Premere un tasto di uso comune e tenerlo pigiato, verificare l'accensione del LED  
2. Se la luce è fissa le batterie sono buone, se LAMPEGGIA sono SCARICHE.

You should only use NEW AAA/R03/UM-4 alkaline batteries that should be changed once a year.  
How to check if the batteries are charged up:  
The flashing red LED doesn't mean the battery is working, it means the BATTERY IS FLAT.  
Check the state of the batteries as follows:  
1. Press a common use button hold it down and check that the red LED lights up.  
2. If the light is steady the batteries are good, but if it FLASHES they are FLAT.